

Blinds Controls

Using the "zipper-style" lever, slide up/ down to open/ close the blinds within the glass panels.



***note: only use the zipper-style lever, because the other levers/handles are used to remove the glass panel. Please do not remove the glass panels**